

scope tower 1/2

fold line

remove

D

fold line

USB scope holder (outer 1/2)

USB scope holder (outer 2/2)

Tower brace

E

scope tower 2/2

fold line

remove

I

I

D

fold line

G

remove

USB scope holder (inner)

H

USB light brace 1/2

B

B

USB light brace 2/2

Plate holder 1/2

F


F

Plate holder 2/2


light diffuser

remove





discard



C

fold line

remove

fold line

remove

A

fold line

fold line